


# **CHILDREN'S ELECTRONIC TOY CAR**

**Model No: JS007**

**ITEM NO: 5194**



- **Suitable for age 3 years+**
- **Maximum user weight: 30kg**
- **Adult assembly required**

## **OWNER'S MANUAL**

**Read and understand this entire manual before using!**

**Please keep this manual for future reference as it contains important information.**

**Before first time use, charge the battery for at least 8 hours.**

**Warning: Vehicle must be charged fully before use,  
Failure to do so voids warranty.**

# Table of Contents

---

1. *About Your New Vehicle*
2. *Parts List*
3. *Parts Diagram*
4. *Assembly Steps*
5. *How To Operation Your Vehicle*
6. *Charging The Vehicle*
7. *Troubleshooting Guide*
8. *Maintaining Your Vehicle*
9. *Disposal Of Battery*

## About Your New Vehicle

---

Thank you for your purchasing our products, we wants your child to enjoy this product for years to come. Keep these points in mind as you read this guide:









<b>Suitable age:</b>	3 years+	<b>Battery:</b>	6V 7AH *1
<b>Load Capacity:</b>	Under 30KGS	<b>Size of car:</b>	97x66x65CM
<b>Speed:</b>	3KM/H	<b>Power way:</b>	Charging type
<b>Charger:</b>	Input: depend on local voltage Output: DC 6V1A	<b>Average battery life:</b>	Approximately 300 times
<b>Charge time:</b>	8-12 Hours	<b>Fuse:</b>	10A

### **WARNING!**





**FOR THE SAFETY OF YOUR CHILD, PLEASE READ ALL WARNINGS AND ASSEMBLY/USE INSTRUCTIONS. KEEP THIS GUIDE FOR FUTURE REFERENCE.**

- **ADULT ASSEMBLY REQUIRED.** The product contains small parts, which are for adult assembly only. Keep small children away when assembling.
- Always remove protective material and poly bags and dispose before assembly.

# Parts List

PART NO.	PART NAME	PICTURE	Q'ty (pcs)	REMARKS	PART NO.	PART NAME	PICTURE	Q'ty (pcs)	REMARKS
1	Vehicle body		1		2	Driving wheel		1	
3	Ø12 Washer		6	Placed on the front axle and rear axle.	4	Ø10 Locknut		4	Placed on the front axle and rear axle.
5	Wheel		3		6	Ø5 Locknut		3	Placed on the front axle plate
7	M5x14 machine screw		3	Placed on the front axle plate	8	Front axle plate		1	Placed in the assembly package
9	Steering shaft		1		10	Ø10 washer		1	
11	Split pin		1		12	Rear axle		1	
13	Ø5 Washer		6	Placed on the front axle plate	14	M5x35 machine screw		1	Placed on the steering wheel

# Parts List

PART NO.	PART NAME	PICTURE	Q'ty (pcs)	REMARKS	PART NO.	PART NAME	PICTURE	Q'ty (pcs)	REMARKS
15	Handle bar		1		16	Seat		1	
17	Charger		1		18	Spanner		2	

# Parts Diagram

**NOTE:** Some Parts Shown are assembled on both sides of vehicle

## Tools Required




Screwdriver(not included)



Pliers(not included)




Spanner




1	Vehicle body *1	2	Driving wheel *1	3	Ø12 Washer *6
4	Ø10 Locknut *4	5	Wheel *3	6	Ø5 Locknut *3
7	M5x14 machine screw *3	8	Front axle plate *1	9	Steering shaft *1
10	Ø10 Washer *1	11	Split pin *1	12	Rear axle *1
13	Ø5 washer *6	14	M5x35 machine screw *1	15	Handel bar *1
16	Seat*1				

# Assembly Steps

- **Your new vehicle requires adult assembly.** Please set aside at least 40 minutes for assembly. Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state. Care should be taken in unpacking and assembly of the vehicle. Children should not handle parts, or help in assembly of the vehicle.
- Please identify all parts before assembly and save all packaging material until assembly is complete to ensure that no parts are discarded.
- Assembly tool for need: screwdriver(not included),pliers(not included) and spanner.




- Turn the vehicle body upside down.
- Remove all the parts from the front axle plate.
- Fit a Ø5 washer against the front axle support.
- Fit the front axle plate against the front axle support.
- Fit a Ø5 washer against the front axle plate.
- Insert the M5x14 machine screw through the Ø5 washer, the front axle, Ø5 washer plate and out through the front axle support, fit and hold a Ø5 washer against the front axle support, then fit a Ø5 locknut to the end of the screw.
- While holding the locknut with the pliers, tighten the screw with a screwdriver.
- Repeat for the other side.




- Remove all the parts from the rear axle.
- Insert the rear axle through the hole in the rear of the vehicle body.


# Assembly Steps



- Fit the driving wheel onto the rear axle. Make it match with the gear box.
- Fit a  $\text{\O}12$  washer onto the rear axle.
- Fit a  $\text{\O}10$  locknut to the end of the rear axle.
- Repeat this procedure to assemble the other driving wheel to rear axle.
- Tighten the locknuts on both sides of rear axle with two spanners. DO NOT over-tighten.




- Remove a  $\text{\O}10$  locknut and a  $\text{\O}12$  washer from the front axle. And leave over a  $\text{\O}12$  washer.
- Fit a wheel onto the front axle.
- Fit a  $\text{\O}12$  washer onto the front axle.
- Fit a  $\text{\O}12$  locknut to the end of the front axle. And tighten with a spanner, DO NOT over-tighten.
- Repeat this procedure to assemble the other wheel to front axle.




- Turn the vehicle body on its side.
- Insert the straight end of the steering shaft up through the hole in the vehicle body.
- Insert the bent end of the steering shaft through the hole in the front axle plate. Fit a  $\text{\O}10$  washer onto the steering shaft, and insert a split pin through the hole in the steering shaft. Bend the ends of the split pin back using a pair of pliers.


# Assembly Steps



- Turn the vehicle body over.
- Remove the M5x35 machine screw and Ø5 nut from the handle bar.
- Insert the handle bar to the end of the steering shaft. Line up the holes in the handle bar with the hole in the steering shaft. Tighten the M5x35 machine screw and Ø5 nut back in the same location with a screwdriver.




- Locate the red connector and plug it into the terminal on battery.



- Insert the tabs on the seat into the slots in the vehicle body, and tighten a M5x14 machine screw to secure it with a screwdriver.

# Assembly Steps

---



**GAP**

## IMPORTANT SUPPLEMENT TO INSTRUCTION MANUAL

After assembling any wheel to the axles, please check the gap between the screw thread and the collapsible (refer to below picture), if the gap is too big, please add two or three washers inside the wheel, But after tightening the nut outside the wheel, please turn the wheel by your finger to check if the wheel can run smoothly, this is very important, because if the wheel can run smoothly, it is ok, but if the nut press the wheel and the wheel can't run smoothly, the motor will be broken easily! Then you need to decrease one or two washers to make sure the wheel can run smoothly!

# How To Operate Your Vehicle

---

## **WARNING!**

### **PREVENT INJURIES AND DEATHS:**

- **NEVER LEAVE CHILD UNATTENDED. DIRECT ADULT SUPERVISION IS REQUIRED.** Always keep child in view when child is in vehicle.
- Never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- Always wear shoes.
- Always sit on the seat.
- Suitable for age 3 years+; Maximum user weight is 30kgs.

### **Must confirm before using that following work which is already finished:**

- **Important!** Before using the vehicle for the first time, the battery needs to be charged for at least 8 hours, no more than 10 hours. Only an adult can charge or recharge the battery.
- Make sure all places with the screw has already been locked.


### **Rules for Safe Riding**

#### **READ THESE RULES ALOUD TO YOUR CHILD AND THEIR PLAYMATES AND MAKE SURE THEY UNDERSTAND THEM!**

- Always wear a helmet when riding.
- Direct Adult Supervision Required.
- Keep Children within Safe Riding Areas:
- Never use in roadway, near motor vehicles, on lawn space, on or near steep inclines or steps, swimming pools or other bodies of water;
- Use the toy only on flat surfaces. such as inside your house, garden or playground.
- Never use in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or a well-lit area.
- It is not recommended to drive the vehicle on wet surfaces or on lopes of greater than 15 degrees.
- Do not use this vehicle outdoors when it is raining or snowing.
- Make sure you come to a complete stop before changing directions from forward to back.
- Please follow the correct weight and age limits allowed to drive this vehicle.
- It is prohibited to change the circuit or add other electric parts
- Inspect wires and connections of the vehicle periodically.
- In order to avoid accidents, please ensure the vehicle is safe before riding.
- Do not let any child touch the wheels or be near them when the car is moving .

# How To Operate Your Vehicle

**Use Operation (The switch is not alight if power switch turned "ON")**



## IMPORTANT!

Always stop vehicle when changing the speed or direction to avoid damage to gear box and motor.

### FORWARD

1. Press the "Forward-backward switch" on the "Forward" position.
2. Press the "Foot pedal", the vehicle drives forward.

### STOP

The vehicle will brake automatically, when your child's foot remove from the "Foot pedal".

### REVERSE

1. Press the "Forward-backward switch" on the "Backward" position.
2. Press the "Foot pedal", the vehicle drives backward.

# Charging Your Vehicle

**ONLY AN ADULT CAN CHARGE AND RECHARGE THE BATTERY!**

## **WARNING!**

### • PREVENT FIRE AND ELECTRIC SHOCK:


- Use the only rechargeable battery and charger supplied with your vehicle. NEVER substitute the battery or the charger with another brand. Using another battery or charger may cause a fire or explosion.
  - Do not use the battery or charger for any other product. Overheating, fire or explosion could occur.
  - NEVER modify the electric circuit system. Tampering with the electric system may cause a shock, fire or explosion or may permanently damage the system.
  - Do not allow direct contact between battery terminals. Fire or explosion can occur.
  - Do not allow any type of liquid on the battery or its components.
  - Explosive gasses are created during charging. Do not charge near heat or flammable materials. Charge the battery in a well-ventilated area ONLY.
  - NEVER pick up the battery by the wires or charger. Damage can occur to the battery and may cause a fire. Pick up the battery by the case ONLY.
  - Charge the battery in a dry area ONLY.
- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after**

# Charging Your Vehicle

## handling.

- Do not open the battery. Battery contains lead acid and other materials that are toxic and corrosive.
- Do not open the charger. Exposed wiring and circuitry inside case may cause electric shock. Only adults may handle or charge the battery. NEVER allow child to handle or charge the battery. Battery is heavy and contains lead acid (electrolyte).
- Do not drop the battery. Permanent damage to the battery could occur or cause serious injury.
- Before charging the battery, check for wear or damage to the battery, charger, its supply cord and the connectors. DO NOT charge the battery if any damage to parts has occurred.
- Do not allow the battery to drain completely. Recharge the battery after each use or once a month if not used regularly.
- Do not charge battery upside down.
- Always secure the battery with the bracket. Battery can fall out and injure a child if vehicle tips over.

- The charging input socket is **AT THE REAR OF THE VEHICLE**.
- The **POWER SWITCH** must be turned in **OFF** position when charging.
- Before the first use, you should charge the battery for 8 hours. Do not recharge the battery for more than 10 hours to avoid overheating the charger.
- When the vehicle begins to run slowly, recharge the battery.
- After each use or once a month minimum recharge time as 8 to 12 hours, less than 20 hours at most.



1. Open the cover of the socket (the socket is at the rear of the vehicle)
2. Plug the charger port into the input socket.
3. Plug the charger plug into a wall outlet. The battery will begin charging.

## **⚠ WARNING!**

This product with **CHARGING PROTECTION**: When charging, all the functions will be cut off!

# Troubleshooting Guide


## ■ PROBLEM: The vehicle does not run

### PROBLEM CAUSE: The battery may low on power.

After each use, or once a month minimum, charge the battery for a full 10 hours. Do not leave the battery on the charger for more than 20 hours.

### POSSIBLE CAUSE: Thermal fuse has tripped.

The vehicle is equipped with a self-resetting fuse. When the vehicle is overloaded or operated incorrectly; the self-resetting fuse will be cut off for 5-20seconds before becoming operational again. The self-resetting fuse is under the seat (Refer to the picture.)



### To avoid the fuse cut off the power, follow these guidelines:

- DO NOT overload the vehicle, Maximum weight allowed :30kg
- DO NOT tow anything behind the vehicle.
- DO NOT drive up steep slopes.
- DO NOT drive into fixed objects, which may cause the wheels to spin, causing the motor to overheat.
- DO NOT drive in very hot weather, components may overheat.
- DO NOT tamper with the electric system, Doing so may create a short circuit, causing the fuse to trip.

### POSSIBLE CAUSE: Wheel nuts are loose.

If the nuts are not tight, the wheels will not engage the forward gears. Tighten the nut with the nut wrench.

### POSSIBLE CAUSE: Battery connector or wires are loose.

Make Sure the battery connectors are firmly plugged in to each other.

### POSSIBLE CAUSE: Battery is dead.

Have you properly maintained the battery according to the directions? Is the battery old? Your battery may need to be replaced.

### POSSIBLE CAUSE: Electric system is damaged.

Water may have corroded the system, or loose dirt, gravel or sand might have jammed the switch.

### POSSIBLE CAUSE: Motor is damaged.

The motor needs professional repair.

## ■ PROBLEM: The battery will not recharge.

### POSSIBLE CAUSE: Battery connector or adapter connector is loose.

Make sure the battery connector and adapter connector are firmly plugged together.

### POSSIBLE CAUSE: Charger is not plugged in.

Make sure the charger is plugged into the wall outlet and the power flow to the outlet is on.

### POSSIBLE CAUSE: Charger is not working.

Is the charger warm while charging? If not, the charger may

# Troubleshooting Guide

---

## ■ **PROBLEM: The vehicle does not run very long.**

### **POSSIBLE CAUSE: Battery may be undercharged.**

You may not be charging the battery long enough. After each use, or once a month minimum, charge the battery for 8 to 10 hours. Do not leave the battery on the charger for more than 20 hours.

### **POSSIBLE CAUSE: Battery is old.**

The battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery should operate for one to three years. Replace the battery with a new one.

## ■ **PROBLEM: Battery buzzes or gurgles when charging.**

This is normal and not a cause for concern. It may also be silent when charging, which is also normal.

## ■ **PROBLEM: Charger feels warm when recharging battery.**

This is normal and not a cause for concern.

# Maintaining Your Vehicle

---

- It is parents' responsibility to check main parts of the toy before using, Must regularly examine for potential hazard, such as the battery, charge,cable or cord, plug, screws are fastening enclosure of other parts and that in the event of such damage, the toy must not be until that damage had been properly removed.
- Make sure the plastic parts of the vehicle are not cracked or broken.
- Occasionally use a lightweight oil to lubricate moving parts such as wheels.
- Park the vehicle indoors or cover it with a tarp to protect it from wet weather.
- Keep the vehicle away from sources of heat, such as stoves and heaters. Plastic parts may melt.
- Recharge the battery after each use. Only an adult can handle the battery. Recharge the battery at least once a month when the vehicle Raider is not being used.
- Do not wash the vehicle with a hose. Do not wash the vehicle with soap and water. Do not drive the vehicle in rainy or snowy weather. Water will damage the motor, electric system and battery.
- Clean the vehicle with a soft, dry cloth. To restore shine to plastic parts, use a non-wax furniture polish. Do not use car wax. Do not use abrasive cleaners.
- Do not drive the vehicle in loose dirt, sand or fine gravel which could damage moving parts, motors or the electric system.
- When not using, all the electrical source should be turn off. Turn off the power switch and disconnect the battery connection.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Where a failure does not amount to a major failure, we are entitled to choose between providing you with a repair, replacement or refund. To obtain compensation, you would need to provide documentary evidence of the loss or damage suffered, and documentary evidence that such loss or damage was a reasonably foreseeable consequence of a failure by us to comply with a consumer guarantee under the Australian Consumer Law. Such evidence may include photographs, statutory declarations, receipts or reports (e.g. from your doctor), depending on the loss or damage.

In addition to all rights and remedies to which you may be entitled under the Competition and Consumer Act 2010 (Commonwealth) and any other relevant legislation, the manufacturer warrants this product to be free from defects in materials or workmanship for a period as stated on the packaging from the date of purchase.

In order to claim under this warranty, you will need to bring the product to the store of purchase, along with proof of purchase (typically this will be a receipt). Any cost incurred by you in bringing the product to the service desk will be borne by you. We will then, at our option, either repair or replace the product, or refund your money and take back the product.

Our liability under this manufacturer's warranty is subject to us being satisfied that a defect was caused by defective workmanship or materials, and was not caused by or substantially contributed to by other factors, or circumstances beyond our control, including (but not limited to) defective installation, maintenance or repair, alteration or modification of the product in any manner not recommended by the manufacturer or any neglect, misuse or excessive use.

The benefits conferred by this manufacturer's warranty are in addition to all rights and remedies conveyed by the Competition and Consumer Act 2010 (Commonwealth), and any other statutory rights to which you may already be entitled, and this warranty does not exclude, restrict or modify any such rights or remedies that are implied by law.

## HUNTER PRODUCTS

Level 2, 424 Warrigal Road Moorabbin 3189

Ph: 1800 224 094

Email: [enquiries@hunterproducts.com.au](mailto:enquiries@hunterproducts.com.au)

# Disposal Of Battery

---

## Disposal Of Battery



- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Do not dispose of your lead-acid battery in a fire. The battery may explode or leak.
- Do not dispose of a lead-acid battery in your regular, household trash. The incineration, land filling or mixing of sealed lead-acid batteries with household trash is prohibited by law.

**PLEASE NOTE:**

IN CASE OF PRODUCT FAULT  
DO NOT RETURN THIS PRODUCT  
TO STORE. PLEASE CONTACT  
Hunter Products Customer Service  
**TOLL FREE NUMBER:**  
1800 224 094  
OR VISIT [WWW.ELECTRICRIDEON.COM.AU](http://WWW.ELECTRICRIDEON.COM.AU)

**FOR CUSTOMER SERVICE OR PRODUCT ENQUIRIES  
PLEASE CONTACT Hunter Products Customer Service  
TOLL FREE NUMBER: 1800 224 094  
OR VISIT [WWW.ELECTRICRIDEON.COM.AU](http://WWW.ELECTRICRIDEON.COM.AU)  
MADE IN CHINA**

**081414**

PLEASE NOTE: IN CASE OF PRODUCT FAULT DO NOT RETURN THIS PRODUCT TO STORE. PLEASE  
CONTACT HUNTER PRODCUTS CUSTOMER SERVICE TOLL FREE NUMBER: 1800 224 094  
OR VISIT [WWW.ELECTRICRIDEON.COM.AU](http://WWW.ELECTRICRIDEON.COM.AU)