

MOTORIZED

MOTORIZED



Shelby GT500

Troubleshooting Guide

Please follow the directions in the attached service guide to check the connections on your ride on. Most times it is a loose plug or switch that causes electric ride's to stop working.

Keep in mind the ride will not operate if the power adaptor/charger cable is plugged into the ride, this is a safety feature to ensure a child does not take off while it's plugged in and damage it.

Disconnect the charger from the car before trying to operate it.

To rule out a faulty fuse:

1. Under the seat in the battery compartment please disconnect the short cable from the red terminal of the battery.
2. Then disconnect the long cable that comes from the ride on wiring to the fuse
3. Connect this cable directly to the red terminal of the battery.

So what you have left over is the small black fuse and a short cable attached to it that are not connected to the ride. This is bypassing the fuse, try this to see if it is in fact a faulty fuse.

If you have a ride on that is 18+ months old and after following these directions you cannot get it going we recommend removing the battery and having the battery & charger tested by a professional.

Batteryworld.com.au offer this service over the counter in your local outlet.


Item#: 2819
Description: Ford Shelby GT500




Step1




Step2



Step3



Step4




Step5




Step6


Please See Next Page



step7



step8



step9

1. Per above steps to check the Forward&Reverse switch's connection.



Step1




Step2




Step3



Step4




Step5




Step6


2. Per above steps to check the wire connection inside the dash board



Step1



Step2



Step3



Step4



Step5




Step6

3. Per above steps to check the connection of Fuse and Pedal Switch.



Step1



Step2



Step3



Step4

4. Per above steps to check the connection of Battery and Gearboxes




Hunter
Products


MOTOR PLUG – PIN TROUBLESHOOT

No. Pin pushed to side.

When plugged together the pin is not connecting with other plug.



Yes. Pin is central.



MOTORIZED