



Item No: 0618
Model No: TR1106B

Maximum user weight is 30KG.

Suitable for ages 3+ years.

Please read manual carefully before use.

Adult assembly required.

This toy have no brake

Warning! Not to be used in traffic

Warning! This toy is unsuitable for children under 3 years due to its maximum speed

The toy should be used with **caution** since skill is required to avoid falls or collisions causing injury to the user or third **parties**.

Always wear a helmet and **protective** clothing when riding.

Continuous adult supervision required when using this product.

Charging the **battery** can only be done by adult at all **times**.

Before first use, charge the **battery** for at least 8-12 hours, no more than 20 hours.

Please keep the manual and packaging for future reference as it contains important **information**.

WARNING: Vehicle must be charged fully before use.

Failure to do so voids warranty.

01. SPECIFICATIONS

02. LIST OF PARTS

03. ASSEMBLY PICTURE

04. FUNCTION OF VEHICLE AND CIRCUIT DIAGRAM

05. FUSE

06. CHARGING FOR THE VEHICLE

07. TROUBLE-SHOOTING

08. MAINTAINING VEHICLE

09. SAFETY PRECAUTIONS


10. DISPOSAL OF BATTERY

01. SPECIFICATIONS

Suitable age	3+ years	Battery	DC 6V 7AH X1
Max. Load	30kg	Size of the car	1100*680*760mm
Speed	2.5-3Km/h	Carton size	1020*670*455mm
Material	PP	Optimum Temperature	Below 40° C Avoid to use under burning sun
Charger	Input: Shown on the charger	Charging time	8-12 hours, at most 20 hours
	Output: DC 6.8V±0.2	Fuse	F 10A, Self-resetting

02. LIST OF PARTS

1.Body 	2.Seat 	3.Guide frame(back section) 
4.Front bumper 	5. Back bumper 	6. Front bumper frame 
7.Front light 	8.Back light cover 	9.Steering wheel 

10. Vent-pipe(left&right) 	11. Side board of the body(left&right) 	12.Wheel(driving wheel*1&else*3) 
13.Screw package: 12pcs 3.5X12 Screws 	14.Screw package: 24pcs 4.0X12 Screws 	15.Handle of the guide frame(left&right) 
16.Windshield 	17.Wheel cover(4pcs) 	

03.ASSEMBLY PICTURE

1.Assemble the back light cover:



(Fig.1)



(Fig.2)

1.1. Fix the back light cover on the back of the body .(According to Fig1 and Fig2)

2.Assemble the black wheel:



(Fig.3)



(Fig.4)



(Fig.5)



(Fig.6)



(Fig.7)



(Fig.8)

2.1. Turn over the body, take the parts away from the back axle,which beside the motor.Then put the driving wheel through the back axle and fix it with washer,nut and wheel cover in turn.(According to Fig3,Fig4,Fig5,Fig6 and Fig8 in turn)

2.2. Take the nut and one piece of washer away from the other side of the back axle.Then put another wheel through the back axle and fix it with washer,nut and wheel cover in turn.(According to Fig3,Fig7,Fig5,Fig6,Fig8 in turn)

3.Assemble the front wheel:



(Fig.9)



(Fig.10)



(Fig.11)

- 3.1. Take one piece of nut and one piece of washer away from one side of the bogie. Put a wheel through the front axle, then fix it with washer, nut and wheel cover in turn. (According to Fig9, Fig10, Fig5, Fig6 and Fig11 in turn)
- 3.2. The other side is same as above.

4. Assemble the side board of the body:



(Fig.12)

- 4.1. Fix the board on both side of the body with 6pcs 4*12 screws. (According to Fig12)

5. Assemble the back bumper:



(Fig.13)



(Fig.14)

- 5.1. Push the two vent-pipes on the back bumper. Then fix the back bumper between the back wheels and the body with 6pcs 4*12 screws. (Detail according to Fig13 and Fig14)

6.Assemble the front bumper:



(Fig.15)



(Fig.16)

- 6.1. Join the front bumper frame together with the front bumper by 5pcs of 3.5*12 screws, then fix them under the bogie with 7pcs of 3.5*12 screws. (According to Fig15, Fig16 and Fig20 in turn)

7.Assemble the front light:



(Fig.17)



(Fig.18)

- 7.1. Turn over the vehicle again, now it is right side up. Then connect the plug under the body. (According Fig17)

- 7.2. The other one is same as above.

8.Assemble the steering wheel:



(Fig.19)



(Fig.20)



(Fig.21)



(Fig.22)

- 8.1. At first connect the plug .Then take away the bolt and the nut in the steering wheel, and put the steering on the steering wheel rod.
- 8.2. Place the bolt through the steering wheel and fix it with nut.(According to Fig20, Fig21 and Fig22 in turn)

9. Assemble the guide frame:



(Fig.23)



(Fig.24)



(Fig.25)



(Fig.26)

- 9.1. Push the handle on each side of the guide frame, fix them on with 4 pcs of 4*12 screws. Then lock the guide frame on the body of the vehicle as Fig26. (According to Fig 23, Fig24, Fig25 and Fig26 in turn)

10. Plug in the battery, assemble the seat and the windshield:



(Fig.27)



(Fig.28)



(Fig.29)



(Fig.30)

- 10.1. Plug in the battery first, red to red.
- 10.2. Take away the two screws as Fig28, then place the seat, and fix it by those two screws as Fig29.
- 10.3. Lock the windshield on the vehicle as Fig30.

WARNING

Before using the vehicle, confirm the following has been done:

- **The vehicle has been assembled strictly according to the steps that the manual described.**
- **The battery has been fixed and inserted correctly and the vehicle has been charged for at least 8-12 hours, no more than 20 hours.**
- **That all screws are tightened.**
- **Let your children know necessary safety rules before allowing them to use the product.**

Reduce the risk of injury:

- **Direct adult supervision required, without leaving children alone when driving.**
- **Always wear shoes.**
- **Please don't overweight, the maximum weight is 30kg.**
- **Most of the material is plastic, so please always keep far away from fire source.**
- **Never driving in the road, street near motor vehicles, ramps, steep inclines, stairs, swimming pools, other sources of water and any else place dangerously.**

04. FUNCTION OF VEHICLE AND CIRCUIT DIAGRAM

1.Introduction of the functions



(1) Turn on the power switch first,the vehicle can move.

(2) Forward

Press the “Forward and Reverse switch” to the “Forward” position.

Press the pedal.

The vehicle drives forward.

(3) Stop

To stop remove foot from the accelerator pedal.

(4) Reverse

Press the “Forward and Reverse switch” to the “Reverse” position.

Press the pedal.

The vehicle drives backward.

5.FUSE

The vehicle is equipped with a self-resetting fuse. When the vehicle is overloaded or operated incorrectly, the self-restting fuse will be cut off for about 15-20 seconds before resuming.

The self-resetting fuse is under the seat(Refer to the picture.)



To avoid electric shock, follow these guidelines:

PLEASE DON'T overload the vehicle. The maximum load is 30 Kg.

PLEASE DON'T tow anything behind the vehicle.

PLEASE DON'T drive the vehicle up the steep slope.

PLEASE DON'T drive into rugged objects, which may cause the wheels to spin, causing the motor to overheat.

PLEASE DON'T drive in very hot weather, components may overheat.

PLEASE DON'T allow water or any other liquids to come in contact with the battery or other electric components.

PLEASE DON'T tamper with the electric system. Or maybe create a short circuit, causing the fuse to trip.

6. CHARGING THE VEHICLE



(Fig.31)



(Fig.32)



(Fig.33)

- The charging socket is in the right of the guide frame as Fig31, shows SOCKET.
- Press the power switch to OFF position to turn the power off.
- Open the seat, connect the battery plug, red to red.

Plug the charger into a 240V mains power wall outlet. (According to Fig32, Fig33)

Before first use, you should charge the battery for 8-12 hours, attentively no more than 20 hours to avoid damage the battery and the charger.

- Never drain battery completely or to a crawling speed, recharge the battery when a decrease in speed and power is noticed warranty will be voided if misuse has occurred.
- After using or at least once a month, recharge for 8 to 12 hours, no more

than 20 hours, if not used regularly

- Battery charging must be done by adults only. Never allow children to charge the battery. A child could be injured by the electricity involved in charging the battery.
- Please don't connect the wires to a short circuit.

The charger and the battery are not a toy. Do not allow children to play with the charger and the battery.

Only operate the battery and charger specified according to the manual instructions.

- Please don't open the battery and the charger.
- Always secure the battery with the bracket. Or battery can be fall out and injure children if vehicle tips over.
- The battery must be handled and operated by adults only. The battery is heavy and contains sulfuric acid (electrolyte). Dropping the battery could result in serious injury.
- Before charging the battery check if wear or damage to the battery, charger, the connectors and other parts. Any damage is found, the charger should be repaired or replace immediately. Do not use a damaged charger.
- It is normal for the adaptor to feel warm during charging, but if the charger feels too hot, stop charging right now and check the battery and adaptor.

7. TROUBLE-SHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE
The 6-Volt battery will not recharge	(1) Battery connector is loose. Make sure the battery connector is firmly plugged in. (2) The 6-Volt battery will not recharge. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on. (3) Charger is not plugged in.

	Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on. (4) Check and replace fuse if necessary.
The vehicle does not run	(1) The battery is dead. Have you properly maintained the battery according to the directions? Is the battery old? Your battery may need to be replaced. Contact Customer Service or Importer (2) Electrical system is damaged. Water may have corroded the system or loose dirt, gravel or sand may have jammed the switch. (3) Motor is damaged. Contact Customer Service or Importer (4) Battery connector is loose. Make sure the battery connector is firmly plugged in. (5) The 6 Volt battery will not recharge. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on. (6) Charger is not plugged in. Make sure the charger is plugged into a 240 Volt wall outlet and the power flow to the outlet is turned on. (7) Check and replace fuse if necessary.
The vehicle does not run for very long	(1) The battery may be undercharged. You may not be charging the battery for long enough. After each use, or at a minimum of once a month, charge the battery for a full 10 - 12 hours. DO NOT leave the battery on the charger for more than 20 hours. (2) The battery is old. The 6 Volt battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery should operate for one to three years. Replace the battery with a new 6 Volt battery. (3) Available through Customer Service or Importer
Battery buzzes or gurgles when charging	This is normal and not a cause for concern. It may also be silent when charging, which is also normal.
The vehicle runs sluggishly or beeping	(1) The battery needs recharging. After each use, or at a minimum of once a month, charge the battery for a full 10 - 12 hours. DO

occurs	NOT leave the battery on the charger for more than 20 hours. (2) The battery is old. The 6 Volt battery will eventually lose the ability to hold a charge. Depending on the amount of use, and varying conditions, the battery should operate for one to three years. Replace the battery with a new 6 Volt battery. (3) The vehicle is overloaded. Maximum weight is 30kg. DO NOT overload the vehicle. DO NOT tow anything behind the vehicle.
---------------	---

8.MAINTAINING YOUR VEHICLE

- It is parent's responsibility to check main parts of the vehicle before using.Regularly examine the vehicle for potential hazards,such as:the battery, charge cable and cord,plug and ensure screws are tightened,If there are any damages,the vehicle must not be used until these damages have been properly repaired or replaced.
- Occasionally use a lightweight oil to lubricate moving parts such as wheels and steering linkages.
- Keep the vehicle in an upturned position,do not overturn or incline it. It is recommended to store the vehicle indoors when not in use,If stored outdoors,the vehicle needs to be covered by a tarp for protection against weather elements.
- This toy should be kept away from fire,Keep the vehicle away from sources of heat,such as stoves and heaters,or plastic parts may melt.While charging ensure all flammable liquids are well away from the vehicle,
- ADULTS ONLY:recharge the battery after each use,Recharge the battery at least once a month when the vehicle is not being used.

- Use a soft,dry cloth to clean the vehicle.
- Please don't use chemical liquid to clean the plastic surface of the vehicle.
- Please don't wash the vehicle with soap and water.
- Please don't drive the vehicle in rainy or snowy weather.Water will damage the motor,electric system and the battery.
- When not in use all the electrical source should be turned off.Press the power switch to OFF position to turn the power off,and disconnect the battery connection under the seat.
- Please don't change the structure of this product and circuit system.
- Please don't use the vehicle for other purposes except riding.

9.SAFETY PRECAUTIONS

01. While riding,adult supervision is required all the time.
02. Always wear a helmet when driving.
03. Please don't drive near road or on the footpath.
04. It is not recommended to drive the vehicle on wet surface or on slope greater than 15-degree.
05. It is recommended to drive this vehicle on smooth surface only,
06. Please don't driving this vehicle outdoors when it is raining.

07. Make sure that the vehicle stop completely before changing direction from forward to reverse.
08. Please don't allow children to operate the charger or play with the battery
09. Clean the vehicle with a dry cloth only.
10. Please follow the correct weight and age limits allowed to drive this vehicle.
11. It is prohibited to change the circuit or add other electric parts.
12. Adults must teach their children about safe driving procedures.
13. Please turn the power off when not in use.
14. Check the seat to ensure it has been fitted and secured with a bolt before driving.
15. Inspect all wires and connections of the vehicle periodically.
16. Charging the battery should only be done by adults.
17. Charging plug is located underneath the seat.
18. In order to avoid accidents, please ensure the vehicle is safe before driving.
19. Please don't let any child touch the wheels or be near them when the car is moving.
20. Warranty period is 90 days from the date of purchase.
21. Proof of purchase must be given for goods to be returned, repaired or replaced.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Where a failure does not amount to a major failure, we are entitled to choose between providing you with a repair, replacement or refund. To obtain compensation, you would need to provide documentary evidence of the loss or damage suffered, and documentary evidence that such loss or damage was a reasonably foreseeable consequence of a failure by us to comply with a consumer guarantee under the Australian Consumer Law. Such evidence may include photographs, statutory declarations, receipts or reports (e.g. from your doctor), depending on the loss or damage.

In addition to all rights and remedies to which you may be entitled under the Competition and Consumer Act 2010 (Commonwealth) and any other relevant legislation, the manufacturer warrants this product to be free from defects in materials or workmanship for a period as stated on the packaging from the date of purchase.

In order to claim under this warranty, you will need to bring the product to the store of purchase, along with proof of purchase (typically this will be a receipt). Any cost incurred by you in bringing the product to the service desk will be borne by you. We will then, at our option, either repair or replace the product, or refund your money and take back the product.

Our liability under this manufacturer's warranty is subject to us being satisfied that a defect was caused by defective workmanship or materials, and was not caused by or substantially contributed to by other factors, or circumstances beyond our control, including (but not limited to) defective installation, maintenance or repair, alteration or modification of the product in any manner not recommended by the manufacturer or any neglect, misuse or excessive use.

The benefits conferred by this manufacturer's warranty are in addition to all rights and remedies conveyed by the Competition and Consumer Act 2010 (Commonwealth), and any other statutory rights to which you may already be entitled, and this warranty does not exclude, restrict or modify any such rights or remedies that are implied by law.

HUNTER PRODUCTS

Level 2, 424 Warrigal Road Moorabbin 3189

Ph: 1800 224 094

Email: enquiries@hunterproducts.com.au

10.DISPOSAL OF BATTERY

Disposal of Battery



- Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.
- Do not dispose of your lead-acid battery in a fire. The battery may explode or leak.

PLEASE NOTE:
IN CASE OF PRODUCT FAULT
DO NOT RETURN THIS PRODUCT
TO STORE. PLEASE CONTACT
Hunter Products Customer Service
TOLL FREE NUMBER:
1800 224 094

FOR CUSTOMER SERVICE OR PRODUCT ENQUIRIES
PLEASE CONTACT Hunter Products Customer Service
TOLL FREE NUMBER: 1800 224 094
MADE IN CHINA